

WaferBOND® CR-200


Temporary Bonding Material

WaferBOND® CR-200 temporary bonding material enables back-end-of-line processing of ultrathin wafers with standard semiconductor equipment.

BENEFITS

- Process ultrathin wafers using standard lithographic, passivation, and metallization techniques and tooling
- Create interconnects before or after thinning
- Preserve delicate structures on III-V devices

Spin Speed Curve



PROCESSING

Best known methods

	20-µm process	
Coat		
Spin speed	1200 rpm	
Acceleration	3000 rpm/s	
Time	30 s	
Bake		
Bake 1	120°C, 3 min	
Bake 2	180°C, 4 min	
Bond		
Temperature	180°C	
Force	3500 N	
Time	2 min	
Vacuum	≤ 5 mbar	

Storage Conditions

Store at room temperature (16° to 26° C)

Debonding Process (Two-Bath Process)

- Bath 1: Submerge in WaferBOND® Remover material at 110° to 130° C for 1 to 4 hours, or until debonded.
- Bath 2: Clean up with WaferBOND® Remover material at 70° to 110° C for 15 minutes to 1 hour. Mild circulation is recommended.
- Rinse: Isopropanol (IPA)
- Dry

Note: The flash point of WaferBOND® Remover material is 77° C. Please ensure that adequate engineering controls are in place before heating WaferBOND® Remover material above this temperature.

Resistance to Process Chemicals

Chemistry	Bath Temp.	Time	
Acetone	25°C	25 min	
NMP	85°C	60 min	
6N HCI	60°C	30 min	
15% H ₂ O ₂	60°C	40 min	
30% NH₄OH	25°C	30 min	
10% KI in H ₂ O	25°C	20 min	
Ethanol	25°C	5 min	
Methanol	25°C	5 min	
Isopropanol	25°C	5 min	
Cyclohexanone	25°C	5 min	
Ethyl Lactate	25°C	5 min	
PGMEA	25°C	5 min	
PGME	25°C	5 min	
30% HCI	25°C	90 min	
70% HNO ₃	25°C	60 min	
Note: An HMDS pretreatment is recommended for the following exposure recipes:			
0.26N TMAH	60°C	30 min	
30% KOH	85°C	60 min	

All statements, technical information, and recommendations contained herein are based on tests we believe to be accurate, but the accuracy or completeness thereof is not guaranteed and the following is made in lieu of warranty expressed or implied. Neither the seller nor the manufacturer shall be liable for any injury, loss, or damage, direct or consequential, arising from the use or inability to use the product. Before using, user shall determine the suitability of the product for his intended use, and user assumes all risk and liability whatsoever in connection therewith. No statement or recommendation contained herein shall have any force or effect unless in an agreement signed by officers of the seller and manufacturer.

Effective Date: 4/27/2018

^{© 2018} Brewer Science, Inc.